

LMD6221 DEFLECTOMETER™ SERIES TWO CHANNEL INDUCTIVE LOOP VEHICLE DETECTOR SPECIFICATIONS

General Characteristics:
Controls: Front panel push buttons allow the user to set the Sensitivity Level, Operational mode, and monitor Frequency independently on each channel. PCB mounted DIP switches allow the user to set the Delay and Extension timers and AccurateCount configuration features.

Sensing Sensitivity - Front Panel Push Buttons:
The DEFLECTOMETER™ front panel 7-segment LED adds in setting the DETECTOR quickly and easily to the most optimum sensitivity level to ensure the trouble-free detection of all vehicles, including motorcycles and high bed vehicles. For typical vehicles (mid-size vehicles) come pick up, adjust, properly installed roadway loop, a Call Strength of 5 displayed on the DEFLECTOMETER™ during the DETECT output period indicates an optimum sensitivity setting. For high profile vehicles (commercial trucks, 4x4s, etc.), a Call Strength value of 4 will be optimum. For low profile vehicles (sports cars, etc.), a Call Strength value of 6 will be optimum.

Adjusting sensitivity using the DEFLECTOMETER™ (recommended):
The DEFLECTOMETER™ should read zero (0) with no vehicle over the roadway loop. When a typical mid-sized vehicle is completely in the detection zone (DET Indicator On), the Call Strength value should be adjusted up or down until the DEFLECTOMETER™ displays the desired optimum value of 4 (or 4 or 5 as described above).

If a typical vehicle located over the roadway loop causes the Call Strength "7" to be displayed on the DEFLECTOMETER™, the sensitivity should be decreased two levels. This can be done by pressing the front panel SENS # button two times to achieve the Call Strength value of 6.

If a typical vehicle located over the roadway loop causes the number "2" to be displayed on the DEFLECTOMETER™, the sensitivity should be increased three levels. This can be done by pressing the front panel SENS # button three times to achieve the Call Strength value of 5.

SENSITIVITY LEVEL CHANGE, ALLOWING YOU TO CHANGE SENSITIVITY SETTINGS WHILE A VEHICLE REMAINS IN THE LOOP DETECTION ZONE.

NOTE: THE DEFLECTOMETER™ CALL STRENGTH DYNAMICALLY UPDATES AFTER EACH SENSITIVITY LEVEL CHANGE.
Adjusting sensitivity without using the DEFLECTOMETER™ (manually setting sensitivity): The DETECTOR offers 9 levels of sensitivity (1 to 9). Level 9 is the highest sensitivity. Sensitivity Level can be manually set to any desired value by pressing the front panel SENS buttons (8 or 9) when a vehicle is NOT over the roadway loop (DET Indicator Off). The first time a SENS button (8 or 9) is pressed, the current Sensitivity Level is displayed on the DEFLECTOMETER™ for 3 seconds. If either SENS button (8 or 9) is pressed again before the 3 second period ends, the Sensitivity Level will increase (SENS #) or decrease (SENS #). The new Sensitivity Level value will be displayed on the DEFLECTOMETER™ display for 3 seconds. The factory default Sensitivity setting is level 6.

Sensitivity	AL/L	Sensitivity	AL/L
9	0.01%	4	0.32%
8	0.02%	3	0.64%
7	0.04%	2	1.28%
6	0.08%	1	2.56%
5	0.16%		

Loop Frequency / Loop Frequency Display: One of four frequency settings may be selected via the front panel FREQ push button to alleviate interference which may occur when loops connected to different detectors are located adjacent to one another. To help prevent or diagnose crosstalk problems, the loop frequency is displayed on the front panel DEFLECTOMETER™. The current loop frequency is displayed after pressing the FREQ button to display the current Frequency Level. The frequency is shown in KHz with a "-" symbol displayed both before and after the numeric digit shown on the DEFLECTOMETER™.

For example, after pressing the FREQ button once the display sequence might show:
"3" → "-" → "2" → "-" → "7" → "-" → "

This sequence would indicate Frequency Level "3" and a loop reference frequency of 27 KHz. Undetected adjacent loops should be separated by at least 5 KHz.

Loop Fault Monitoring: The Detector continuously checks the integrity of the loop. The system is able to detect shorted or open circuit loops, or sudden changes in inductance exceeding 25% of the nominal inductance. If a fault is detected, the OUT and FLT indicators continuously emit a sequence of flashes. Additionally, the DEFLECTOMETER™ displays the letter "F" indicating a current loop fault. Each type of fault is identified by a unique flash sequence:

Flash Sequence	Fault
1 flash	Open Circuit Loop.
2 flashes	Shorted Circuit Loop.
3 flashes	25% excessive change in inductance.

If the Open or Shorted fault condition self heals, the DET Indicator and DEFLECTOMETER™ will return to normal operation. The FLT Indicator will continue to flash with the sequence signifying the type of fault that was first detected. In the case of the excessive inductance change fault, the unit will return to the new inductance after a period of two seconds and continue operation. The fault condition will be indicated by the flash sequence of the FLT indicator.

Operational Modes:
Presence: For each channel, a Presence output mode may be selected from the front panel MODE push button. If presence mode is selected then a choice of short (S) or long (L) can be selected. Short Presence is defined as 30 minutes and Long Presence is defined as 120 minutes.
Pulse: For each channel, a Pulse output mode (P) may be selected from the front panel MODE push button. In Pulse mode, a 125 ms ± 25ms width pulse will be output for each vehicle entering the loop.

Call: For each channel, a continuous CALL output (C) may be selected from the front panel MODE push button which will simulate the presence of a vehicle. This mode is used for testing the CALL output of a channel.

Channel Off: For each channel, the Channel Off (O) may be selected from the front panel MODE push button. This option turns OFF the channel and disables the oscillator. An additional option allows the Status Output to be turned ON while the channel is OFF.

Selectable Outputs:
Call Delay Timer (or Presence & Pulse Modes): For each channel, a delay time of 1 to 99 seconds may be selected by setting the appropriate PCB mounted DIP switches to the ON position. Call Delay time starts counting down when a vehicle enters the loop detection area. During the Delay time the DET Indicator will flash two times per second and the DEFLECTOMETER™ will display the letter "d". Delay time can be overridden by a True (On) signal at the Timer Control input.

Call Extension Timer for Presence Mode: For each channel, an extend time of 0.25 to 1575 seconds can be set via the EXTEND DIP switches. The numeric sum of the switches in the On position is equal to the Extend time. Two modes are provided:

Extend Always (default): Call Extend time starts counting down when the last vehicle clears the loop detection zone. During the Extend time the DET Indicator will flash four times per second and the DEFLECTOMETER™ will display the letter "E". Any vehicle entering the loop detection zone during the Extend time period causes the Extend timer to be reset and the output maintained. The Timer Control input has no effect on this mode.

Extend on Green (EOG):

Call Extend time starts counting down when the last vehicle clears the loop detection zone if the Timer Control input is True (On). During the Extend time the DET Indicator will flash four times per second and the DEFLECTOMETER™ will display the letter "E". Any vehicle entering the loop detection zone during the Extend time period causes the Extend time to be reset and the output maintained.

The Extend on Green mode is enabled by a factory installed diode located at OPT6 on the PCB. Consult the factory for details.

Timer Control Inputs: Timer Control inputs are provided for each channel to modify the operation of the Delay and Extension functions. The application of a True (On) state voltage will inhibit the Delay (only) function and/or enable the Extend (only) function. Timer Control inputs are primarily provided for downward compatibility.

PIN	FUNCTIONS	PIN	FUNCTIONS
A	Logic Ground	1	Ch. 1 Timer Control Input
B	DC Supply	2	Ch. 2 Timer Control Input
C	Internal Reset	3	No Connection
D	Ch. 1 Loop Input	4	Ch. 1 Redundant Loop Input
E	Ch. 1 Loop Input	5	Ch. 1 Redundant Loop Input
F	Ch. 1 Output (+)	6	No Connection
G	Ch. 1 Output (-)	7	Ch. 1 Status Output
H	Ch. 2 Loop Input	8	Ch. 2 Redundant Loop Input
J	Ch. 2 Loop Input	9	Ch. 2 Redundant Loop Input
K	Ch. 2 Loop Input	10	No Connection
L	Chassis Ground	11	No Connection
M	No Connection	12	No Connection
N	No Connection	13	No Connection
P	No Connection	14	No Connection
R	No Connection	15	No Connection
S	No Connection	16	No Connection
T	No Connection	17	No Connection
U	No Connection	18	No Connection
V	No Connection	19	No Connection
W	Ch. 2 Output (+)	20	Ch. 2 Status Output
X	Ch. 2 Output (-)	21	No Connection
Y	No Connection	22	No Connection
Z	No Connection		

DC Supply Voltage: Minimum 12.8 Vdc
Maximum 28.8 Vdc

DC Supply Current: Maximum 100 mA

DC Timer Control Inputs: True (On) Less than 8 Vdc
False (Off) Greater than 16 Vdc

Optically Isolated Outputs: True (On) Less than 1.5 Vdc
Maximum Current 100 mA

Outputs are fail-safe such that a Defector with no power will provide the True (On) Call State.

Relay Outputs: AC Contact Rating 5A @ 120 Vdc
DC Contact Rating 5A @ 30 Vdc

Environmental: Operating Temperature Range: 30°F to 165°F (-34°C to 74°C)

Mechanical: International Case 4.50071 (116.30mm) x 6.876" (174.63mm) x 1.200" (30.48mm), excluding handles, with 44 pin double sided edge connector.

Status Output:
Each channel includes a separate output which is used to transmit operational status information to a bus interface unit (BIU). Fault information is transmitted by means of pulse-width modulation. Pulse widths shown are +10%.

Status	Status Output Condition
Normal operation / No Fault	Continuous ON (Pwm)
Watchdog / No Power Supply Fail	Continuous OFF (Pwm)
Open Circuit Loop	50ms OFF, 50ms ON
Short Circuit Loop	100ms OFF, 50ms ON
25% change in inductance	150ms OFF, 50ms ON